

## Modifications: (changes from VASS)

Tensions:

M.P.T. 2% 0

3% 1"

4% 2"

4% 4"

4% 6"

1/4" off bottom of cast maintaining same contours

1. Apply all reductions in the posterior 2/3 of the limbs soft tissue avoiding prominent bony structures.
2. Just clean up anterior portion of cast of sock marks and any irregular shapes from casting under vacuum.
3. This inner socket should be a 1 sheath fit over liner and one sheath fit over inner socket